

ing at 6 MPH.
6-7-12. See dia-
spark plug dis-

M. Metric type.

Distributor.
gle 36.5° closed
550 RPM (distr.)

g.
marks provided.
edure and Vac-
te opening at

b. Equipment.
x. 7/8 turn open.
raps.), 350 Eng.

or minus 1/32"
hole—Summer,
(#3) hole—Ex-
; lbs. max.).

(hydraulic type
ator, Regulator.

umn and igni-
post and igni-
linder and keys.

Ignition Switch
Oakes No.
302406
302406
302406
302406
e Model 268H32.
o. 26H-3677-A
eal), 268H-3677

and similar to previous designs except for new
automatic advance data (given below).
Firing Interval—Movable contacts open 37 1/2° after
fixed set with unequal intervals of 37 1/2° and 22 1/2°

Distributor Removal:—Mounted on front of engine.
To remove, remove generator, disconnect vacuum
line and primary leads, remove distributor caps,
take out 3 cap screws in mounting flange.

